

GUARDALL

IN FLOOR SAFES

RECOMMENDED INSTALLATION PROCEDURE.

The safes may be installed in either concrete or timber floors. The opening in the floor should be at least 500mm square by 500mm deep.

The safe should be secured with a strong mix concrete 1 x sand, 1 x stone, 1 x cement. Steel reinforcing material can also be used to help bond the concrete and provide better security.

It is recommended that the mix be poured so that a concrete cover of at least 100mm (4") exists around each side of the safe and brought level with top.

Floor safes are not waterproof. In damp situations the concrete should contain a waterproofing agent such as "Silasec" or "Yurite" (available from hardware stores). Whilst the concrete is setting, the door should be removed.

INTERCHANGEABLE DOOR REMOVES TO FACILITATE SERVICE & INSTALLATION.



FLUSH FITTING LID TO AID CONCEALMENT AND FIRE PROTECTION.

MADE IN AUSTRALIA

ALL CMI SAFES COME WITH A FIVE YEAR WARRANTY, EXCLUDING FREIGHT & TRAVELLING, WITH A 12 MONTH WARRANTY ON LOCKS.